Capacitor Control Solutions From Telescada



CAPACITOR CONTROL



Autonomous Capacitor Control Functions & Capacitor Bank Monitoring

- Voltage Control
- Temperature Control
- Time of Day Control
- Var Control
- Neutral Current Monitoring
- 3 Φ Voltage, Current and Var Measurement

2-Way Wireless Distributed Control

- DNF
- Modbus RTU & ASCII





PRODUCT BRIEF

A revolution in Distribution Capacitor Controls, the Telescada NeXVar™ Capacitor Control incorporates a simple to use, intuitive touchscreen to view control status and real-time information. Quickly and easily view and modify autonomous Capacitor Control schemes and Control functionality or choose from a library of pre-set, 1-click Control "personalities"™

The NeXVar's™ wide angle, full color display makes obsolete the ancient blinking lights, rotary dials, toggle switches and 2-line displays of old fashioned capacitor controls.

Password protected Bluetooth and WiFi connectivity makes viewing, modifying and controlling the NeXVar™ a snap from the comfort and safety of your vehicle with your Smart Phone.



Control the NeXVar[™] with the NeXVar[™] Smartphone App



222 Bolivar Street Canton, Massachusetts USA TEL: 781-562-0475 sales.desk@telescada.com

Monitor, Alarm, Record, Communicate and Control

www.Telescada.com